



Window Settings Explained

- **Mouse Post-select:** this turns on the mouse key within Windows and displays on the desktop.
- **Mouse Post-select Settings:** allows you to configure the mouse layout and function of the mouse keys.
- **Auto-Hide Windows Keyboard:** this turns off the Windows keyboard and prevents it opening when a text field is selected.
- **Windows Clicks:** 'ON' allows for mouse clicks in Windows using eye gaze. 'OFF' will disable mouse click activations while maintaining cursor control - useful with 'mouse over' or 'hover' activities in third party computer programs.
- **Magnify Windows Clicks:** Provides a magnification pane upon each activation on the screen in Windows with eye gaze. Helpful when accessing very small targets. 1. Magnification Factor: range of 2x - 5x. Use the Up/Down arrows to adjust the power of the magnification 2. Magnification Area: range 64 x 64 - 256 x 256. Use the Up/Down arrows to adjust the size of the magnification pane.
- **Magnification Factor:** this setting determines how big you magnify the magnify window x2, x3, x4 or x5.
- **Magnification Area:** This determines the area of the screen that is magnified, the choices are 64 - 256.
- **Magnify Windows Keyboard:** this allows you the choice to magnify the Windows keyboard, the choices are on or off.
- **Windows Selection Type:** you can change the selection type, for example have a different dwell time to that used in the MAP, it can be: Same; Dwell; Blink; or Switch

Liberator contacts

Regional Consultants

Mark Street: 07747016660

Eleri Davies: 07827324286

Jacqui Malthouse 07825512669

Office

Technical Support: 01733 370470
(Option 2)